



Alarm Clock

MyTime Funky Colour

Art. No. 8010050

EN Instruction Manual

Contents

1 Imprint	3
2 Features.....	3
3 About this Instruction Manual	3
4 General safety instructions	4
5 Parts overview and scope of delivery	5
6 Screen display	6
7 Establishing the power supply (mains operation)	6
8 Establishing the power supply (Battery operation, optional)	7
9 Automatic time setting.....	7
10 Manual time setting	7
11 Alarm setting.....	7
12 Snooze function.....	7
13 Automatic measurement display	8
14 Display change	8
15 Display brightness regulation	8
16 Disposal.....	8
17 EC Declaration of Conformity	8
18 Warranty	8

1 Imprint

Bresser GmbH

Gutenbergstraße 2
46414 Rhede
Germany

<http://www.bresser.de>

For information regarding liability claims or service requests, please refer to chapters "Warranty" and "Service" in this documentation. We ask for your understanding, that any requests or submissions that have been addressed to the manufacturer's address can not be processed.

Errors reserved - technical specifications subject to change.

© 2017 Bresser GmbH

All rights reserved.

It is not allowed to reproduce this documentation or parts of it in any kind (e.g. photocopying, printing, etc) without written a permission of the manufacturer. It is also prohibited to use or transmit this documentation with electronic systems (e.g. image file, website, etc).

The descriptions and brand names of the corresponding firms used in this documentation are generally protected under trademark, brand and/or patent law for Germany, for the European Union and/or other countries.

2 Features

- Radio-controlled clock with DCF signal reception and display
- Alarm with snooze function
- Indoor temperature (in °C or °F)
- Automatic summer/winter time changeover
- Control elements on the backside
- Incl. power adapter an cable
- Battery operation possible alternatively
- Can be placed on a flat surface

3 About this Instruction Manual



NOTICE

These operating instructions are to be considered a component of the device.

Please read the safety instructions and the operating instructions carefully before use.

Keep these instructions for renewed use at a later date. When the device is sold or given to someone else, the instruction manual must be provided to the new owner/user of the product.

4 General safety instructions



DANGER

Danger of an electric shock!

This device contains electronic components that operate via a power source (power supply and/or batteries). In case of any improper use of this device, there is a risk of an electric shock. An electric shock can cause severe injury or even death. Therefore please read the safety instructions below to avoid an explosion.

- Children must only use the device under adult supervision! Only use the device as described in the manual; otherwise, you run the risk of an electric shock.
- Disconnect the device from the power supply by pulling the power plug when it is not used or in case of longer interruption of operation and before starting any work on maintenance and cleaning.
- Position your device so that it can be disconnected from the power supply at any time. The wall socket you use should be located near the device and easily accessible, since the plug on the power cable serves as a disconnecting device for the power supply.
- Always pull on the plug to separate the device from the power supply. Never pull on the cable.
- Before operating, check the device, cables and connections for damage.
- Never use a damaged unit or a unit with damaged power cables. Damaged parts must be exchanged immediately by an authorised service centre.
- Only use the device in complete dry environment and do not touch it with wet or moist parts of your body.



DANGER

Danger of choking!

In case of any improper use of this device, there is a risk of choking, especially for children. Therefore please read the safety instructions below.

- Keep packaging material, like plastic bags and rubber bands, out of the reach of children, as these materials pose a choking hazard!
- This product contains small parts that could be swallowed by children. There is a risk of choking!



DANGER

Danger of explosion!

In case of any improper use of this device, there is a risk of an explosion. Therefore please read the safety instructions below to avoid an explosion.

- Do not expose the device to high temperatures. Use only the supplied power supply or the recommended batteries. Do not short-circuit the device or batteries or throw them into a fire! Excessive heat or improper handling could trigger a short circuit, a fire, or an explosion.



NOTICE

Risk of property damage!

In case of any improper use of this device and/or its accessories, there is a risk of property damage. Therefore only use the device according to the safety instructions below.

- Do not disassemble the device. In the event of a defect, please contact your dealer. The dealer will contact the Service Centre and can send the device in to be repaired, if necessary.
- Do not expose this device to higher temperatures and protect it from water and high humidity.

- Do not immerse the unit in water!
- Protect the device from severe shocks!
- For this device only use accessories and spare parts that comply with the technical information.
- Use only the recommended batteries. Always replace weak or empty batteries with a new, complete set of batteries at full capacity. Do not use batteries from different brands or with different capacities. Remove the batteries from the unit if it has not been used for a long time.



NOTICE

Risk of voltage damage!

The manufacturer is not liable for voltage damage due to improperly inserted batteries or through the use of an improper power adapter!

5 Parts overview and scope of delivery




Illustration 1: Parts overview for the radio-controlled alarm clock

1 Display	2 SNOOZE/DIMMER button (snooze function or display brightness setting)
3 TIME button	4 DOWN button (value change downwards or initializing radio signal)
5 UP button (value change upwards or display change)	6 ALARM button (alarm time setting or display change)
7 Battery compartment	8 DC connection socket for coaxial/barrel connector
9 Battery compartment cover	10 Power cable with coaxial/barrel connector
11 DC power adapter with EU mains plug.	

Scope of delivery

Radio-controlled alarm clock (A), power adapter (B)

Recommended batteries (not included)

2 pcs. Micro batteries (1.5V, AAA type)

6 Screen display




Illustration 2: Screen display for the radio-controlled alarm clock

1 Alarm time (hours)	2 Alarm time (minutes)
3 Symbol for alarm time setting	4 alarm timer (hours)
5 alarm timer (minutes)	6 Symbol for radio signal
7 AM/PM information in 12-hour time mode	8 Current time (hours)
9 Symbol for active daylight saving time (DST)	10 Current time (minutes)
11 Current time (seconds)	12 Date (day)
13 Date (month)	14 Temperature unit (°C or °F selectable)
15 Temperature value	16 Weekday
17 Symbol for active alarm	

7 Establishing the power supply (mains operation)

1. Put the DC connector into the connection socket of the device.
2. Put the mains plug into the power outlet.
3. The device is energized directly.

8 Establishing the power supply (Battery operation, optional)

1. Remove the battery compartment cover.
2. Insert the batteries into the battery compartment. Ensure that the battery polarity (+/-) is correct.
3. Replace the battery compartment cover.

9 Automatic time setting

After the power supply was established, the clock will automatically search for the radio signal. This will take approximately 3 to 8 minutes to finish this process.

If the radio signal is received correctly, the date and time will be set automatically and the radio control signal icon turns on.

If the clock fails to receive the time signal, go ahead with the following steps:

1. Press and hold the DOWN button for approx. 2 seconds to re-initialize radio signal reception.
2. If the device still not receiving the signal, the time must be set manually.

Read the detailed manual for more information about manual time and alarm time settings (see download information on page 2).

10 Manual time setting

1. Press and hold TIME button for approx. 3 seconds to switch to settings mode. 24Hr display will flash.
2. Press UP or DOWN button to change the setting.
3. Press TIME button to switch to the next setting. Settings order: 12/24-hours mode > Time zone > Hours > Minutes > Year > Month > Day > Language > °C/°F
4. Press UP or DOWN button at each setting to change the relevant value.
5. Finally press the TIME button to save the settings and exit the setting mode.

11 Alarm setting

1. Press and hold ALARM button for approx. 2 seconds to enter the alarm time setting mode.
2. Digits to be set are flashing.
3. Press UP or DOWN button to change the value.
4. Press ALARM button to confirm and continue to the next setting.
5. Settings order: Hours > Minutes
6. Finally press the ALARM button to save the settings and exit the setting mode. Alarm will be activated automatically. ⏰ symbol will be displayed.
7. Press ALARM button in normal display mode to display the alarm time.
8. Press UP button during the alarm time display to disable the alarm. ⏰ symbol is not displayed.

12 Snooze function

1. Press SNOOZE/DIMMER button when the alarm sounds to activate the snooze function. The alarm will sound again in 5 minutes.
2. Press ALARM button when the alarm sounds to interrupt the alarm until the alarm time will be reached again.
3. The alarm will be turned off automatically if no button is pressed within 2 minutes.

13 Automatic measurement display

Measurements for the indoor area will be displayed on the device once power supply was enabled.

Read the detailed manual for more information about readings (see download information on page 2).

14 Display change

- Press ALARM button to switch between current time display and alarm time display.
- Press UP button to switch between date display and the display for the countdown/timer until next alarm.
- Press TIME button to switch between weekday display and seconds display.

15 Display brightness regulation

1. In normal display mode press SNOOZE/DIMMER button to activate full display brightness for approx. 5 seconds.
2. Press and hold SNOOZE/DIMMER button for approx. 3 seconds to change the display brightness. Next brightness level will be set automatically. Brightness levels: bright > medium > dark

NOTICE! In battery mode the display brightness regulation is disabled. Display will remain in dark display mode to save power.

16 Disposal



Dispose of the packaging materials properly, according to their type, such as paper or cardboard. Contact your local waste-disposal service or environmental authority for information on the proper disposal.

Do not dispose of electronic devices in the household garbage!

As per Directive 2002/96/EC of the European Parliament on waste electrical and electronic equipment and its adaptation into German law, used electronic devices must be collected separately and recycled in an environmentally friendly manner.

In accordance with the regulations concerning batteries and rechargeable batteries, disposing of them in the normal household waste is explicitly forbidden. Please make sure to dispose of your used batteries as required by law — at a local collection point or in the retail market. Disposal in domestic waste violates the Battery Directive.

Batteries that contain toxins are marked with a sign and a chemical symbol. "Cd" = cadmium, "Hg" = mercury, "Pb" = lead.

17 EC Declaration of Conformity



Bresser GmbH has issued a "Declaration of Conformity" in accordance with applicable guidelines and corresponding standards.

18 Warranty

The regular guarantee period is 2 years and begins on the day of purchase. To benefit from an extended voluntary guarantee period as stated on the gift box, registration on our website is required.

You can consult the full guarantee terms as well as information on extending the guarantee period and details of our services at www.bresser.de/warranty_terms.

Service

DE AT CH BE

Bei Fragen zum Produkt und eventuellen Reklamationen nehmen Sie bitte zunächst mit dem Service-Center Kontakt auf, vorzugsweise per E-Mail.

E-Mail: service@bresser.de
Telefon*: +49 28 72 80 74 210

BRESSER GmbH
Kundenservice
Gutenbergstr. 2
46414 Rhede
Deutschland

*Lokale Rufnummer in Deutschland (Die Höhe der Gebühren je Telefonat ist abhängig vom Tarif Ihres Telefonanbieters); Anrufe aus dem Ausland sind mit höheren Kosten verbunden.

GB IE

Please contact the service centre first for any questions regarding the product or claims, preferably by e-mail.

e-mail: service@bresseruk.com
Telephone*: +44 1342 837 098

BRESSER UK Ltd
Unit 1 starborough Farm,
Starborough Road, Nr Marsh Green,
Edenbridge, Kent TN8 5RB
Great Britain

*Number charged at local rates in the UK (the amount you will be charged per phone call will depend on the tariff of your phone provider); calls from abroad will involve higher costs.

FR BE

Si vous avez des questions concernant ce produit ou en cas de réclamations, veuillez prendre contact avec notre centre de services (de préférence via e-mail).

e-mail: sav@bresser.fr
Téléphone*: 00 800 6343 7000

BRESSER France SARL
Pôle d'Activités de Nicopolis
260, rue des Romarins
83170 Brignoles
France

*Prix d'un appel local depuis la France ou Belgique

NL BE

Als u met betrekking tot het product vragen of eventuele klachten heeft kunt u contact opnemen met het service centrum (bij voorkeur per e-mail).

e-mail: info@folux.nl
Teléfono*: +31 528 23 24 76

Folux B.V.
Smirnoffstraat 8
7903 AX Hoogeveen
Nederlands

*Het telefoonnummer wordt in het Nederland tegen lokaal tarief in rekening gebracht. Het bedrag dat u per gesprek in rekening gebracht zal worden, is afhankelijk van het tarief van uw telefoon provider; gesprekken vanuit het buitenland zullen hogere kosten met zich meebrengen.

ES IT PT

Si desea formular alguna pregunta sobre el producto o alguna eventual reclamación, le rogamos que se ponga en contacto con el centro de servicio técnico (de preferencia por e-mail).

e-mail: servicio.iberia@bresser-iberia.es
Teléfono*: +34 91 67972 69

BRESSER Iberia SLU
c/Valdemorillo,1 Nave B
P.I. Ventorro del cano
28925 Alcorcón Madrid
España

*Número local de España (el importe de cada llamada telefónica dependen de las tarifas de los distribuidores); Las llamadas des del extranjero están ligadas a costes suplementarios.